

Cable PS6

Note: Use Heat shrink sleeve on both sides to all cables.
Cable Length is without connector.
Color code given is recommended color code.
Twist the cables.

**FP - Front Plate, BP - Back Plate, PS - Power Supply, DC - Data Cable
SP - Side Plate**

Cable: - PS6 +12V Power Connection

Length: 40 cm, Twisted Wire

Specification of Connector 1: 3 Pin Relimate [F] 2.54mm on J12 on 2K10005V5

Specification of Connector 2: 2 Pin Relimate [F] on J24 PCB 2K12032

